



USER INSTRUCTIONS


PMV D3 Digital Positioner

Installation

Operation

Maintenance

FCD PMENIM0001-03 - 12/14



Contents

1. Introduction	3
Safety instruction	3
2. Storage	5
General	5
Storage indoors	5
Storage outdoors or for a longer period	5
Storage in a warm place	5
3. Design	6
4. Variants	7
5. Function	8
6. Installation	9
Removal of covers	9
Tubing	9
Air supply requirements	9
Mounting	10
Connections	11
Single action positioner, Direct function	12
Double action positioner, Direct function	12
Electrical connections	13
Signs	15
D3 Digital Positioner model code	16
7. Control	17
Menus and pushbuttons	17
Other functions	17
Menu indicator	18
Menus	18
Changing parameter values	18
Menu system	19
First start	20
8. Maintenance/service	36
Disassembling PMV D3	36
Silencer	38
Potentiometer	39
Transmitter boards	39
Disassembling PMV D3 Ex	42
Filter change	43
9. Trouble shooting	44
10. Technical data	44
11. Dimensions	47
12. Spare parts	50

1. Introduction

The PMV D3 is a digital positioner designed primarily for controlling adjustable valves. The positioner can be used with single or double action actuators with either rotary or linear movement.

The PMV D3 can be equipped with modules for feedback, limit switches and a pressure gauge block. Pressure sensors can be installed in the pneumatic block to offer advanced diagnostics. The modules can be factory assembled before

delivery or fitted later. The modules for feedback and limit switches can contain the following:
Feedback 4-20 mA and one of the following functions:
- Two mechanical contacts
- Two reed switches
- Two inductive sensors, EN60947-5-6



Safety instruction

Read the safety instructions in this manual carefully before using the product. The installation, operation, and maintenance of the product must be done by staff with the necessary training and experience. If any questions arise during installation, contact the supplier/sales office before continuing work.

Warning

- The valve package moves when in operation and can cause personal injury or damage if handled incorrectly.
- If the input signal fails or is switched off, the valve moves quickly to its end position.
- If the compressed air supply fails or is turned off, fast movements can occur.
- The valve is not controlled by the input signals when in the Out of service mode. It will open/close in the event of a leak.
- If a high value is set for Cut off, fast movements can occur.
- When the valve is controlled in the Manual mode, the valve can move quickly.
- Incorrect settings can cause self-oscillation, which can lead to damage.

Important

- Always turn off the compressed air supply before removing or disconnecting the air supply connection or the integral filter. Remove or disconnect with care because C- is still under pressure even after the air supply is turned off.
- Always work in an ESD protected area when servicing the PCB's. Make sure the input signal is switched off.
- The air supply must be free from moisture, water, oil and particles.

Special Conditions for Safe Use

The enclosure of PMV D3I (Intrinsically safe) is made of aluminium and any impact or friction caused by external objects shall be avoided in the application.

All spare parts for certified products for hazardous locations

(Ex and IS) are only available for certified service facilities.

Palmstierna International AB (PMV Positioners) will only supply spare parts for Explosion proof or Intrinsically safe products to certified purchasers. In order to be allowed to purchase spare parts for IS and EX products the purchaser must be registered by proper Notified Body and covered under PMV QAN.

According to IEC 60079-19 section 4
4.4.3.2 Modifications are not permitted.

If the equipment is modified the user shall be informed in writing that the equipment is no longer suitable for use in an explosive atmosphere.

Should you have any questions with regards to this, please feel free to contact us anytime.



2. Storage

General

The PMV D3 positioner is a precision instrument. Therefore it is essential that it is handled and stored in the right way. Always follow the instructions below!

N.B. As soon as the positioner is connected and started, internal air leakage will provide protection against corrosion and prevent the ingress of moisture. For this reason, the air supply pressure should always be kept on.

Storage indoors

Store the positioner in its original packaging. The storage environment must be clean, dry, and cool (15 to 26°C, 59 to 79°F).

Storage outdoors or for a longer period

If the positioner must be stored outdoors, it is important that all the cover screws are tightened and that all connections are properly sealed. The unit should be packed with a desiccant (silica gel) in a plastic bag or similar,

covered with plastic, and not exposed to sunlight, rain, or snow.

This is also applicable for long-term storage (more than 1 month) and for long transport by sea.

Storage in a warm place

When the positioner is stored in a warm place with a high relative humidity and is subjected to daily temperature variations, the air inside the unit will expand and contract.

This means that air from outside the unit may be drawn into the positioner. Depending on the temperature variations, relative humidity, and other factors, condensation and corrosion can occur inside the unit, which in turn can give rise to functional disorders or a failure.

3. Design

The PMV D3 positioner contains:

- Electronic board with microprocessor, HART modem, Profibus, Foundation Fieldbus, display, etc.
- Valve block
- Positional feedback with potentiometer
- Sealed compartment for electrical connections.


The push buttons and display are accessible underneath the aluminium cover, which is sealed with an O-ring.

A PC configurator is available free of charge on our webpage www.pmv.nu

The only requirements are: D3 positioner must have HART communication and a HART modem for connection between PC and positioner.


With the configurator, settings can be done and saved in the PC, then downloaded to the positioner.

Filter **Pressure sensors** **Display, control push buttons**



The figure shows the **PMV D3** with the cover removed.

Valve block **Positional feedback**



The figure shows the **PMV D3E** with the covers removed.

Air vent protection cap
(Make sure it is installed, facing upwards, before taking the unit into service.)

4. Variants

PMV D3 General purpose

The PMV D3 digital positioner has an easy to use user interface with 5 pushbuttons and local graphic LCD display. Communication options include 4-20mA HART, Foundation Fieldbus and Profibus PA. All PMV D3 positioners are available with Feedback, Fail Freeze (Fail in last position and hold when power is lost), 270-degree rotation (for extended travel) and Gauge block.



PMV D3 Intrinsically safe

The PMV D3 digital positioner is available in intrinsically safe version for installation in hazardous areas. The intrinsically safe PMV D3 has all the same features and options as the general purpose version, gauge block, local graphic LCD display and feedback option etc. Communication with Hart, Profibus and Foundation Fieldbus is possible.

ATEX:

⊕ II 1G Ex ia IIC T4 Ga Ta:80°C / IP66

PMV D3 Explosion proof

The PMV D3 digital positioner is available in explosion proof enclosure. The explosion proof PMV D3 features the same easy to use interface for local configuration as the **general purpose** version does. Communication with Hart, Foundation Fieldbus and Profibus is possible. Further features are gauge ports and local graphic LCD display.

ATEX:

⊕ II 2G Ex d IIB+H₂ T6 Ta:60°C
II 2D T85°C, Ta:80°C / IP66

CSA, FM


Class I, Div.1 Grps B, C, D
Class II, Div.1 Grps E, F, G
Class III, Div.1
T6, T5 / Type 4X



Pressure sensors

Pressure sensors can be installed in the pneumatic block in order to provide advanced diagnostics in combination with ValveSight software.

5. Function



The control signal function and the feedback from the potentiometer position are converted to digital signals that are processed with a PID algorithm in the microprocessor. This provides control signals to the two piezo-valves.

Valves B and E deliver air to the actuator while valves C and F exhaust air from the actuator to atmosphere. Valves B and C are controlled by Piezo-valve 1 and valve A. Valves E and F are controlled by Piezo-Valve 2 and valve D.

Full supply pressure is directed to valves B and E. Air with filtered and reduced pressure is supplied to valves A, C, D and F.

For double acting actuators, connect C+ and C- to the actuator.

For single acting (spring return) actuators connect C+ to the actuator and plug port C-. Single acting versions have the air block plugged in one end as default. To convert from double to single acting function - see page 11.

Increasing input signal changes position in piezo-valve 1, causing valve A to close.

Supply pressure is then allowed to open valve B and flow to the actuator via the C+ port. When the actuator reaches its new steady state position piezo-valve 1 closes which causes valves B and C to close shutting off supply air to the actuator.

A decreasing input signal functions in the same manner, except uses piezo-valve 2 and valves D, E and F.

6. Installation


Removal of cover

General purpose / Intrinsically safe

Remove cover by first loosening the screw 1 and then the two screws 2.

To install cover, first tighten the screw 1, then the two screws 2.

Tighten to 1,5 — 2 Nm.




Explosion proof

To remove covers, first unscrew securing screws, then unscrew covers.

To install, screw covers on as far as possible. Mount the securing screws. Back off slightly on the large cover to be able to screw down the securing screw completely.

Securing screws



Tubing

Use tubes with a minimum inner diameter of Ø 6 mm (1/4").

Air supply requirements

Poor quality in air supply is the main cause of problems in pneumatic systems.

The air supply must be free from moisture, water, oil and particles and delivered @ 2-7 bar (30-105 psi)

Standard: **DIN/ISO 8573-1-2001 3.2.3**

Filtered to 5 Micron, dew point -40°C/F

Oil 1mg/m³ (0,83 ppm by weight)

The air must come from a refrigeration dried supply or be treated in such a way that its dew point is at least 10°C (18°F) below the lowest expected ambient temperature.

To ensure a stable and problem-free air supply, we recommend the installation of a filter/pressure regulator <5µ as close to the positioner as possible.

Before the air supply is connected to the positioner, we recommend the hose is opened freely for 2 to 3 minutes to allow any contamination to be blown out. Direct the air jet into a large paper bag to trap any water, oil, or other foreign materials. If this indicates that the air system is contaminated, it should be properly cleaned.



WARNING! Do not direct the open air jet towards people or objects because it may cause personal injury or damage.

Mounting


N.B. If the positioner is installed in a hazardous environment, it must be of a type approved for this purpose.

The PMV D3 positioner, all versions, has an ISO F05 footprint, A. The holes are used to attach the PMV D3 to the mounting bracket B. Please contact PMV or your local distributor representative with actuator specifics for the proper mounting bracket and hardware.


The spindle adapter C can be changed to suit the actuator in question.

It is important that the positioner's spindle and the lever arms, that transfer the actuator movements, are correctly mounted. Any tension between these parts can cause incorrect operation and abnormal wear.

Spindles



Assembly examples



Connections

Air:

- Port S Supply air, 2-7 bar (30-105 psi)
- Port C+ Connection to actuator, opening
- Port C- Connection to actuator, closing (only for double action)
- Plug for single action, see below

Electrical connection

See page 13, 14.

Dimensions

Air connections:

1/4" NPT alt. G 1/4"

Electrical connection:

M20 x 1.5 alt. NPT 1/2"

Loctite 577 or equivalent is recommended as a sealant.


Converting the D3 between single acting and double acting mode

When using the D3 (all versions) in single acting mode, the external C- port as well as the air block need to be blocked. (Air block plug installed per default when ordered for single acting use.)



Plug the air block (acc. to the picture) with the nylon plug and o-ring. (item 3-45).

When in double acting mode, the nylon plug must be removed and the C- port connection opened.

Must be plugged when converting to single action function.



External air Connection




For data for air and electrical connections, see section Technical Data on page 45.

Single action positioner, Direct function

Actuator with closing spring


When the control signal increases, the pressure C+ to the actuator is **increased**. The valve stem moves upward and rotates the positioner spindle **counter-clockwise**. When the control signal drops to zero, C+ is vented and the valve closes.



Reverse function

Actuator with opening spring


When the control signal increases the pressure C+ to the actuator is **increased**. The valve stem moves downward and the positioner spindle rotates **clockwise**. When the control signal drops to zero, C+ is vented and the valve opens.



Double action positioner, Direct function

Double action actuator

When the control signal increases, the pressure C+ to the actuator is increased. The valve stem is pressed upward and rotates the positioner spindle counter-clockwise. When the control signal is reduced, the pressure C- to the actuator increases and the valve spindle is pressed downward. If the control signal disappears, the pressure goes to C-, C+ vents, and the valve closes.



Fail in place (Fail Freeze)

When the input signal drops below 3,75 mA, the Fail Freeze function holds the actuator/valve at current position.

Drift rate in midrange <0,1% after 30 s and < 2% after 30 min.

Electrical connections


Terminal block diagram for the PMV D3 and PMV D3 Ex.

PMV D3

The terminal block (below) for the positioner is accessible when the aluminium cover and inner cover are removed, see Section 8.

Remote unit

The remote unit shall be connected between terminals 3, 4 and 5 in the PMV D3 and 7, 8 and 9 in the remote unit. Use a shielded cable and ground it to the PMV D3 or to the remote unit. (Not both units at the same time.)




Warning! In a hazardous environment where there is a risk of explosion, electrical connections must comply with the relevant regulations.

Max distance between PMV D3 and remote unit: 5 m (16,4 ft).


Note! When connecting the PMV D3 or PMV D3 Ex to a remote unit, modifications have to be done internally with a cable. Details found on www.pmv.nu

When installing the PMV D3 Intrinsically safe unit - always consider control drawing 3-86 found at www.pmv.nu/downloads.

Connecting a remote unit



Shielded cables, grounded on the PMV D3.



PMV D3 Ex

The terminal (below) for the positioner is accessible when the terminal cover is removed, see Section 8.


See cdwg 3-86



Warning! In a hazardous environment where there is a risk of explosion, electrical connections must comply with the relevant regulations.

PMV D3 Ex

Connection




Remote unit

- 1 Input signal + 4-20 mA , Hart, Profibus PA, Foundation Fieldbus
- 2 Input signal - 4-20 mA , Hart, Profibus PA, Foundation Fieldbus
- 3 Remote unit
- 4 Remote unit Optional
- 5 Remote unit Optional
- 9 4-20 mA + Feedback, 13-28 V DC
- 10 4-20 mA - Feedback, 13-28 V DC
- 11 Alarm output +, 8-28 V DC
- 12 Alarm output -, 8-28 V DC

PMV D3 Ex Profibus DP

Connection



Remote unit

- 1 Input signal +24V Profibus DP
- 2 Input signal -24V Profibus DP
- 3 Remote unit
- 4 Remote unit Optional
- 5 Remote unit Optional
- P Profibus DP Communication
- N Profibus DP Communication
- DGND Digital Ground

Type sign examples

General purpose and Intrinsically safe housing

FLOWERVE D3IGU-D23PVA-Z5XX

Ex II 1G Ex ia IIC T4 Ga, Ta=-30...+80°C, NEMKO 03ATEX110X
INTRINSICALLY SAFE/SECURITE INTRINSIQUE-Exia
 When installed in accordance with installation drawing:3-86C
WARNING! Substitution of components may impair intrinsic safety.
AVERTISSEMENT! La substitution de composants peut compromettre a securite intrinsique.

CE 0470

IP66/Nema 4x FISCO field device

Flowserve, Sweden
 Palmstierna International
 Solna, Sweden
 www.flowserve.com

3-88C

S/N

Explosion proof housing

EXPLOSION PROOF DIGITAL VALVE POSITIONER

Product Code: D3abcdeeffghij

Class I Div.1 Grps. B,C&D Class II Div1 Grps E,F&G
 T6(Ta:+65°C/+149°F) T5(Ta:+80°C/176°F) Type 4X

Ex d IIB+H ₂	T6 Ta:+60°C	IP66
CE 0470 Ex II 2GD	T85°C Ta: 80°C	NEMKO 03ATEX 111
Ex d IIB+H ₂	T6 Gb Ta: +60°C	IP66
Ex tb IIIC	T85°C Db Ta: +80°	IECEx NEM 09.0001

Electrical Rating: max 28V DC, max24mA, max0,67W
 Do not open while energized! Seal within 50 mm of the enclosure.
 Max. working pressure: 700kPa/100 psl

PALMSTIERNA INTERNATIONAL AB, SOLNA SWEDEN

Prod year-serial number P/N: D3E-XX

D3 Digital Positioner model code

A=	Model no	
	D3X	Digital positioner with display and indicator, General purpose
	D3Z	Digital positioner with display and indicator, General purpose, Direct mount to Flowact
	D3I	Digital positioner with display and indicator, Intrinsically safe ATEX
	D3Y	Digital positioner with display and indicator, Intrinsically safe ATEX, Direct mount to Flowact
	D3E	Digital positioner with display, no indicator, Explosion proof ATEX, CSA/FM
	D3F	Digital positioner with display, Explosion proof ATEX, FM, IEC Direct mount to Flowact
B=	Connections	
	G	1/4" G air, M20 x 1,5 ectrical
	N	1/4" NPT air, 1/2" NPT electrical
	M	1/4" NPT air, M20 x 1,5 electrical
C=	Surface treatment	
	U	Powder epoxy
D=	Function	
	S	Single acting
	L	Single acting, Fail Freeze
	P	Single acting, Fail freeze remote mounted
	M	Single acting, remote mounted
	D	Double acting acting
	H	Double acting high-flow (A=D3X only)
	T	Double acting high-flow remote (A=D3X only)
	K	Double acting Fail Freeze function
	Q	Double acting Fail freeze remote mounted
	R	Double acting Remote mounted
E=	Spindle	
	23	Rotary VDI/VDE 3845
	39	D type with thread/nut for Linear actuators
	09	Double D type & adator spindle for 01/02/06/21/26/30/36/41
	BA	BASF special unit with, Spindel 39 With adapter
F=	Cover and Indicator (No indicator on D3E, D3F)	
	PVA	Black PMV, 90 deg, Arrow indicator
	PVB	Black, Extended travel, 270 deg Arrow indicator
	FSW	White cover, Flowserve, 90 deg, Arrow indicator
	FSY	Yellow cover, Flowserve, 90 deg, Arrow indicator
	WCA	Worcester Controls, Arrow indicator
G=	Sensors/Temperature/seals	
	Z	No pressure sensors, NBR -30 to 80 deg C
	Y	On Board pressure sensors, NBR -30 to 80 deg C
H=	Input signal/Protocol	
	4	4-20 mA
	5	HART, 4-20 mA
	P	Profibus PA
	D	Profibus DP
	F	Foundation Fieldbus
I=	Feedback option (Limitations for D3E)	
	X	No feedback option
	T*	Plug in 4-20 mA transmitter only + Alarm module
	S*	Limit switches MEC + 4-20 mA + Alarm
	N*	Limit sensors NAM + 4-20 mA + Alarm
	P*	Limit switches PXY + 4-20 mA + Alarm
	4*	Slot type Namur sensor, P+F SJ2 S1N + Alarm
	5*	Slot type Namur sensor, P+F SJ2 SN + Alarm
	6*	Slot type Namur sensor, P+F SJ2N + Alarm
J=	Accessories	
	X	No accessories
	M	Gauge block For D3X, D3I only, For D3E (default) Gauge ports D3E, D3F (default)
	1	Gauge block incl 1 gauge included stainless/brass
	2	Gauge blocks incl 2 gauges included stainless/brass
	3	Gauge blocks incl 2 gauges included stainless/brass

A A A B C - D E E F F F - G H I J

*Not for D3E, D3F

7. Control


Menus and pushbuttons

The positioner is controlled using the five push-buttons and the display, which are accessible when the aluminium cover is removed.

For normal functioning, the display shows the current value. Press the ESC button for two seconds to display the main menu.

Use the pushbuttons  to browse through the main menu and the sub-menus.

The main menu is divided up into a basic menu and a full menu, see page 19.



Other functions

ESC

Exit the menu without making any changes (as long as any changes have not been confirmed with OK).

FUNC

To select function and change parameters.

OK

To confirm selection or change of parameters.

MENU INDICATOR

Displays the position of the current menu row in the menu.

IN SERVICE

The positioner is following the input signal. This is the normal status when the positioner is working.

OUT OF SERVICE

The positioner is not following the input signal. Critical parameters can be changed.

MANUAL

The positioner can be adjusted manually using the pushbuttons. See section "Man/Auto", page 27.

UNPROTECTED

Most of the parameters can be changed when the positioner is in the "Unprotected" position. However, critical parameters are locked when the positioner is in the "In service" position.

Menu indicator


There are indicators at both sides of the display window and they indicate as follows:

Flashing in position **Out of service**

Flashing in position **Manual**

Displayed in position **Unprotected**

The indicators on the right-hand side show the position in the current menu.



Menus

To display the menus you can select:

- **Basic menu**, which means you can browse through four different steps
- **Full menu**, which comprises ten steps. Use the Shift Menu to browse through the steps

Full Menu can be locked out using a passcode.

The main menus are shown on the next page and the sub-menus on the subsequent pages.


Changing parameter values

Change by pressing \leftarrow \rightarrow until the desired figure is flashing.

Press \updownarrow to step to the desired figure. Confirm by pressing OK.

A change can be undone by pressing the **ESC** button, which returns you to the previous menu.

Menu system



The menus are described on the following pages.

**BASIC MENU
CALIBRATE**



First start

”Calibrate” is displayed in the basic menu automatically, the first time power is applied. It can be selected from the basic/main menu at any time.

A complete auto-calibration takes up to 30 minutes depending on size of actuator and includes end limit calibration, auto-tuning, leak test and a check of the movement speed. Start the automatic calibration by selecting **Auto-Cal** and then answer the questions in the display by pressing **OK** or the respective arrow. The menu is described on page 23.

Calibration error messages

If a fault occurs during calibration, one of the following error messages can be displayed:

No movement/press ESC to abort

Typically the result of an air delivery issue to the actuator, or incorrect mounting and/or linkage arrangement. Check for proper supply air to the positioner, pinched tubing, proper actuator sizing, proper linkage and mounting arrangement.

Pot uncalibrated/press ESC to abort

The potentiometer has been set to an illegal value. The potentiometer is aligned using the Calibrate - Expert cal - pot Menu. The calibration sequence must be restarted after the fault is corrected.

Air leak detected/ESC = abort

OK = go on

An air leak has been detected. The calibration sequence should be restarted after the fault is corrected.

First start, Profibus PA/DP

For Profibus PA, connect the input signal at pos 1 and 2 on the terminal block. For Profibus DP, connect power to pos 1(+) and 2(-) and communication to pos 6 and 7. See Electrical connections in the manual.

In the SETUP/Devicedata/Profibus: change the address from 126 to any number between 1-125. Never use the same number with more than one unit. Install values in failsafe mode, for communication when loss of signal. Calibrate the unit. GSD files are available at our web-page www.pmv.nu

To install the D3_PROFIBUS.DDL file to Siemens SIMATIC PDM.

1. Move the files to The directory with the DeviceInstall.exe. There should be one existing from Siemens that is included in PDM
2. Run the Program DeviceInstall.exe

Parameter	Description	BYTE
SP	Setpoint	The SP has 5 bytes, 4 bytes for the float value and one status byte that has to be 128 or over (80 in hex) for the D3 to accept it. Use 128 means GOOD and everything should work fine. 4+1=5
READBACK	Position	The READBACK has 5 bytes, 4 bytes for the float value and one status byte. 4+1=5
POS_D	Digital position	Gets a position in digital form 0 = Not initialized 1 = Closed 2 = Opened 3 = Intermediate 2
CHECKBACK		Detailed information of the device, bit wise coded, more than one message possible at ones.3
RCAS_IN	Remote Cascade	The RCAS_IN has 5 bytes, 4 bytes for the float value and one status byte. 4+1=5
RCAS_OUT	Remote Cascade	The RCAS_OUT has 5 bytes, 4 bytes for the float value and one status byte. 4+1=5

Status Byte Table

MSB	LSB meaning	D3 use
0 0 0 0 1 0 x x	not connected	
0 0 0 0 1 1 x x	device failure	PROFibus PA module failure
0 0 0 1 0 0 x x	sensor failure	No sensor value
0 0 0 1 1 1 x x	out of service	AI Function Block in O/S mode
1 0 0 0 0 0 x x	Good -	Non cascade measured value OK All Alarm values used
1 0 0 0 0 0 0 0	OK	
1 0 0 0 1 0 0 1	Below low limit Lo	Advisory alarm
1 0 0 0 1 0 1 1	Above high limit Hi	Advisory alarm
1 0 0 0 1 1 0 1	Lo-Lo	Critical alarm
1 0 0 0 1 1 1 1	Hi-Hi	Critical alarm

Example SP = 43.7% and 50%

Float	Hex	Status
43.7	42 2E CC CD	80
50.0	42 48 00 00	80

(FF) Foundation Fieldbus function blocks

Function blocks are sets of data sorted by function and use. They can be connected to each other to solve a control process, or to a controlling DCS. To get a good introduction and understanding of FF look at www.fieldbus.org and download the "Technical Overview" from the About FF pages.

(TB) Transducer Block

The TB contains unit specific data. Most of the parameters are the same as parameters found on the display. The data and the order of data varies between different products. The AO-block setpoint (SP) and process value (PV) parameters are transceived to the TB through a channel. The TB has to be in AUTO for the AO-block to be in AUTO.

The positioner has to be in menu-auto mode and in service to be controlled from the fieldbus. If the positioner is placed in menu-manual mode then the transducer block will be forced to (LO) local override. In this way a person in the field will be able to control the positioner from the keypad, without collision with a control loop.

(RB) Resource Block

The RB is a set of parameters that looks the same for all units and products. The values of the RB define unit information that concerns the Fieldbus Protocol such as MANUFAC_ID which informs the unique manufacturer id. For Flowserve it is 0x464C53. The RB has to be in AUTO for the AO-block to be in AUTO.

(AO) Analogue Output Block

The AO follows Fieldbus Foundation's standard on content and action. It is used for transferring (SP) setpoints from the bus to the positioner.

CAS_IN (cascade input) and RCAS_IN (remote cascade input) are selected as inputs to the AO block depending on the MODE_BLK parameter.

The selected input will be relayed to the SP parameter of the AO block. BKCAL_OUT (back calculated output) is a calculated output that can be sent back to a controlling object so that control bumps can be avoided. Usually the BKCAL_OUT is set to be the (PV) process value of the AO-block, i.e. the actual measured position of the valve.


OUT is the primary calculated output of the AO block. During a limited action (ramping) of the AO block the RCAS_OUT parameter will supply the final setpoint and the OUT parameter will be the limited output. The transducer block is connected through a channel to the AO block. Through this channel the OUT value and SP are transceived.

In order to set the AO block to AUTO, the TB and the RB have to be in AUTO. Further the AO block has to be scheduled. Using National Instruments Configurator; scheduling can be done by adding the unit to a project and then click on the "upload to device"-icon.


To write a setpoint value by hand, add Man to MODE->Permitted parameter, and then choose MODE->Target to Man. Make sure that the unit is scheduled.

Example

A typical FF block loop control might look like the following:
Where the positioner is represented by the AO-block.



AO-block overview



The contents of the menu are shown on the next page. The various menu texts are described below.

Auto-Cal Start tune

Auto-tuning and calibration of end positions
Starts the tuning. Questions/commands are displayed during calibration. Select the type of movement, function, etc. with and confirm with **OK** as shown in the chart on the next page.

Lose prev value? OK?

A warning that the value set previously will be lost (not during the first auto-tuning).

- Actuator? rotating**
- Actuator? linear**
- Actuator single act**
- Actuator double act**
- Direction? direct**
- Direction? reverse**

- Select for rotating actuator.
- Select for linear actuator.
- Select for single act.
- Select for double act.
- Select for direct function.
- Select for reverse function.

In service? Press OK

Calibration finished. Press OK to start positioner functioning. (If ESC is pressed, the positioner assumes the "Out of service" position but the calibration is retained).

TravelCal

Start cal Lose prev value? OK?

Calibration of end positions
Start end position calibration. A warning that the previously set value will be lost. Confirm with OK.

In service? Press OK

The calibration sequence starts. Calibration finished. Press OK to start positioner functioning. (If ESC is pressed, the positioner assumes the "Out of service" position but the calibration is retained).

Perform

- Normal**
- Perform 50%, 25%, 12%, L, M, S**
- L, M, S**
- Factory set**

Setting gain
100% gain
Possibility to select a lower gain in steps. Preset values for L, M, S actuators Resets all set values and enters Factory Mode. **Should only be used by authorized staff.**

Note. Original P. I. D. will always be shown in display

ExpertCal

Set point LO: Use the calibrator set to 4 mA (or set another value on the display). Press OK.

Set point HI: Use a calibrator of 20 mA (or set another value on the display). Press OK.

Pressure LO: Use a supply of 2 bar (30 psi) (or set another value on the display). Press OK. Pressure read out only possible on PMV D3 with built in pressure sensor.

Pressure HI: Use a supply of 7 bar (105 psi) (or set another value on the display). Press OK. Pressure read out only possible on PMV D3 with built in pressure sensor.

Transmitter: Connect 10 - 28 VDC. Connect an external mA meter to the loop. Read low value on mA meter and adjust with up/down key. Press OK to set low value. Repeat procedure to set High value. Also see video on www.pmv.nu

Pot: Potentiometer setting, see section 8. Also see video on www.pmv.nu

Full reset: Resets all set values.

Feedback option

Feedback kit: D3-As38P

Microswitchkit: D3-As38M

Nemursensokit: D3-As38N or D3-As38(O4/D5/D6)

Reedschichtkit: D3-As38P

Feedback kit: D3-As38T

Mechanical & Proximity switches

P-F Namur sensors

IMPORTANT:
For D3 IS units (Intrinsically Safe):
- Transmitter card NOT for on site mounting by customer.
- FM, CSA and ATEX certificates only valid when transmitter card is mounted by manufacturer.

Calibration of the 4-20 mA transmitter

Go to menu shown in diagram, read out value. Adjust output signal using Up or Down key until meter I reads 4.00 mA. Finish by pressing OK. Repeat the above for 20 mA.

MECHANICAL SWITCHES
SPDT
Sub-Sun Miniature
Size: 3A 125V AC / 2A 30V DC *

NAMUR SENSORS P-F
Proximity DIN 19234 NAMUR
Load current: $2 \text{ mA} > 3 \text{ mA}$
Voltage: 12V DC
Hysteresis: 0.2 %
Temperature: -20C to 85C (-4F to 185F)

PROXIMITY SWITCHES
SPDT
Operating time: 250 ms
Operating voltage: 12V DC
Contact resistance: 0.1 Ohm
Mechanical/Electrical life: >30000000 operations

4-20 mA TRANSMITTER
Supply: 10-28V DC
Resolution: 0.1 %
Accuracy: $\pm 0.1 \text{ %}$
Output current limit: 30 mA DC
Load impedance: 800 Ohm @ 24V DC
* Switch rating limited to 100 mA/50V DC/42V AC for D3 units with connection board D3-4335 R1

Mounting instruction

PART NO.	PCS	DESCRIPTION	MATERIAL	REVISION
070029	1	MA-METER CONNECTIONS MOVED TO TERMINALS 9 & 10		070029 (REV)
070036	1	TERMINALS 13 AND 14 REMOVED, TERMINAL 13 CH. 14 BORTLAGD		070036 (REV)
070037	1	TERMINAL 13 CH. 14 BORTLAGD		070037 (REV)
070038	1	NOTE ADDED, PROXIMITY RESPONDING IS UNITS		070038 (REV)
070039	1	SWITCH STATE ADJUSTED AND MENU PATH CHANGED		070039 (REV)
070040	1	DESCRIPTION, INT. CHANGE		070040 (REV)

Connect a mA meter I to terminal 9 & 10.

Calibrator Expert cal → Expert cal Transm. → Transm. low Transm. low LO= 4.0mA → Transm. hi Transm. hi HI= 20.0mA → OK

4.00 mA

20.00 mA

OK

OK

When installing the transmitter card, make sure it is placed correct over the connector pins before gently pushing it down until it is seated. Secure the PC board with the two screws. Make sure the holes are centred before tightening the screws.

Note! When installing the cam assembly for mechanical switches, retract both the switch pins, set cam assembly and tighten the screws loosely to obtain enough friction to lock the cams. Then tighten the screws. Secure cams setting by tighten the two screws hard. The upper cam should trip switch/sensor no. 2.

For more information see manual chapter 8, Transmitter boards.

The menu contents are shown in the figures on the right and the texts are described below:




Current values can be read using the Read Menu and some values can be reset.

- Pos** Shows current position
- Set&pos** Set point and position
- Set&dev** Set point and deviation
- Pos graph** Shows position graph
- Temp** Shows current temperature

- Statistics**
- n cycles** Shows number of movements (turns)
- Pulse rate** Shows pulse rate
- Acc travel** Shows accumulated movement
- mean dev** Shows accumulated deviation in %
- m.abs dev** Shows accumulated absolute deviation in %
- # of resets** Shows number of resets
- runtime** Shows accumulated runtime since last reset
- Extr temp** Shows extreme min and max temperature
- Histogram** Shows position and time for position value

- Alarms** Displays tripped alarms



The Man/Auto menu is used to change between manual and automatic modes.

The menu contents are shown in the figures on the right and the various texts are described below:



- AUT, OK = MAN**
Positioner in automatic mode
- MAN, OK = AUT**
Positioner in manual mode

When changing between **MAN** and **AUT** mode, the **OK** button must be pressed for 3 seconds.

In the **MAN** mode, the value of POS can be changed using \triangle ∇ . The push-buttons increase/decrease the value in steps. The value can also be changed in the same way as for the other parameter values, as described on page 18


- Other functions**
- C+ can be fully opened by pressing \triangle and then immediately OK simultaneously.
- C- can be fully opened by pressing ∇ and OK simultaneously.
- C+ and C- can be fully opened for blowing clean by pressing \triangle ∇ and OK simultaneously.



The Shift Menu is used to choose between the basic menu and the full menu.

The menu contents are shown in the figures on the right and the various texts are described below:

- No** Full menu selected.
- Yes** Basic menu selected.




Full Menu can be locked with a passcode, see Setup menu.



The Status Menu is used to select whether or not the positioner is in service.

The menu contents are shown in the figures on the right and the various texts are described below:

- o o service** Not in service. Flashing indicator in upper left-hand corner of display.
- in service** Positioner in service. Critical parameters cannot be changed.



When changing between **In service** and **Out of service**, the **OK** button must be pressed for 3 seconds.



The Setup Menu is used for various settings.

The menu contents are shown in the chart on the next page and the various texts are described below:


<u>Actuator</u>	<u>Type of actuator</u>	<u>Size of actuator</u>	<u>Time out</u>
Rotating	Rotating actuator.	Small	10 s
Linear	Linear actuator.	Medium	25 s
		Large	60 s
		Texas	180 s

Lever Only for linear actuator.
Lever stroke Stroke length to achieve correct display.
Level cal Calibration of positions to achieve correct display.

<u>Direction</u>	
Direct	Direct function (signal increase opens). Indicator/spindle rotates counter-clock wise.
Reverse	Reverse function.

Character Curves that show position as a function of input signal.

Linear	See diagram.
Equal %	
Quick open	
Sqr root	
Custom	



Cust chr	
# of point	Specify number of points (3, 5, 9, 17, or 33)
Cust curve	Enter values on X and Y axes.

Curr range	
0%=4.0 mA	
100%=20.0 mA	Possibility of selecting which input signal values will correspond to 0% and 100% movement respectively. Examples of settings: 4 mA = 0%, 12 mA = 100%, 12 mA = 0%, 20 mA = 100%.

TRVL range 0%=0.0%	<u>Setting end positions</u> Select Out of Service. Set percentage value for desired end position (e.g. 3%).
Set 0%	Select In Service. Connect calibrator. Move forward to desired end position (0%) and press OK.
100%=100.0%	Select Out of Service. Set percentage value for desired end position (e.g. 97%).
Set 100%	Select In Service. Connect calibrator. Move forward to desired end position (100%) and press OK.
Trvl ctrl	<u>Behaviour at set end position</u>
Set low	Choose between Free (go to mechanical stop), Limit (stop at set end position), and Cut off (go directly to mechanical stop at set end position). Similar to Set low.
Set high Values	Select position for Cut off and Limit at the respective end positions.
Passcodes	<u>Setting passcodes for various functions</u>
Full menu	Passcode for access to full menu.
Write prot	Passcode for removing write protect.
Expert	Passcode for access to Expert menu (TUNING).
Fact set	Passcode to return to default values applicable when positioner was delivered.
Numbers between 0000 and 9999 can be used as passcodes. 0 = no passcode required.	
Appearance Language Units	<u>On display</u> Select menu language. Select units.

Def. Display	Select value(s) to be displayed during service. The display reverts to this value 10 minutes after any change is made.
Start menu	Start in Basic menu or Full menu.
Orient	Orientation of text on display.
Par mode	Display of control parameters such as P, I, D or K, Ti, Td.
Devicedata	General parameters.
HW rew	
SW rew	
Capability	
HART	Menu with HART parameters. Only amendable with HART communicator. It is possible to read from display.
Profibus PA/DP	Indicates present status Serial number 1-126 Allotted ID ID description SW release date Value = preset pos Time = Set time +10sec= time before movement Valve act = failsafe (preset pos) or lastvalue (present pos) Alarm out= On/Off
Status	
Device ID	
Address	
Tag	
Descriptor	
Date	Name provided by the DCS system
Failsafe	
Foundation Fieldbus	Name provided by the DCS system
Device ID	
Nod address	
TAG-PD_TAG	Name provided by the DCS system
Descriptor	
Date	
Sim jumper	



The menu contents are shown in the chart on the next page and the various texts are described below:

Close time	<u>Minimum time (Min 0.005) from fully open to closed.</u>
Open time	<u>Minimum time (Min 0.05) from closed to fully open.</u>
Deadband	<u>Setting deadband. Min. 0.2%.</u>
Expert Control	<u>Advanced settings.</u> See explanations below.
Togglestep	Test tool for checking functions. Overlays a square wave on the set value.
Self test	Internal test of processor, potentiometer, etc.
Leakage	Air leakage in actuator/tubing can be compensated by settings.
Undo	You can read last 20 changes.

P,I,D and K,Ti,Td parameters

If one of the gains is changed, the corresponding value in the other gain set is changed accordingly.

Min Pulse

The minimum pulse lengths (the "minpulses") are displayed in the menu, and can be changed. Normal values are:
DN1, DN2: 2750 to 4300
UP1, UP2: 3750 to 5220

Reduction of pulses

This function monitors the number of pulses vs time. In case of an excessive number of pulses vs. time, an automatic reduction of pulses is enabled in order to extend the service life. This function is enabled as default.

Spring adjust

The spring adjust function compensates the airflow linearly with the actuator C+ chamber volume (for a constant position error), so that low volumes get less flow. This is needed for linear single-acting actuators, where a low C+ volume means that the actuator spring is extended, its force is reduced, and less flow is needed for stable position changes.

**FULL MENU
ALARMS**


The menu contents are shown in the chart on the next page and the various texts are described below:

Deviation On/Off Alarm generated when deviation occurs
Distance Allowed distance before alarm is generated.
Time Total deviation time before alarm is generated.
Alarm out Select ON/OFF offers output on terminals.
Valve act Behaviour of valve when alarm is generated.

Limit 1 On/Off Alarm above/below a certain level.
Minipos Setting of desired min. position.
Maxpos Setting of desired max. position.
Hysteresis Desired hysteresis.
Alarm on Select ON/OFF offers output on terminals.
Valve act Behaviour of valve when alarm is generated.

See diagram below!

Limit 2 See Limit 1.



Temp On/Off Alarm based on temperature
 Temperature alarm on/off.
Low temp Temperature setting.
High temp Temperature setting.
Hysteresis Allowed hysteresis.
Alarm out Select ON/OFF offers output on terminals.
Valve act Behaviour of valve when alarm is generated.


Valve act

No action Alarm generated only. Operations not affected.
Goto open C+ gives full pressure and valve moves to fully open position. Positioner changes to position Manual.
Goto close C- gives full pressure and valve moves to fully closed position. Positioner changes to position Manual.
Manual Valve stays in unchanged position. Positioner moves to position Manual.

**FULL MENU
FACT SET**

The menu contents are shown in the chart below.

The default values that were set on delivery can be reset using the Fact Set menu. Values from calibration and from other settings will then be lost.



**Single Board
12 terminals**

READ			pos set&pos	n cycles	
MAN/AUTO	AUT,OK=MAN	MAN,OK=AUT	S&P actual	acc travel	
CALIBRATE	AutoCal		set&dev	mean dev	
	TravelCal		Pos Graph	m. abs dev	
	Leak test		Supply Pr**	runtime	
	Pulse tune		C+ & C-**	# of reset	
	Step tune		temp	extr temp	
	Play est		statistics	histogram	
	Frict est		alarms	reset stat	
	Perform	Setpoint	normal		
	Expert cal	Pressure	50%		
		Transm.	25%		
	pot	12%			
	full reset	preset L			
		preset M			
		preset S			
		factory se			
SHIFT MENU	Basic menu				
	Full menu				
STATUS	O O SERVICE				
	IN SERVICE				
SETUP	Actuator	type	Rotating	small	
		function	Linear	medium	
	size		large	Texas-size	
	Lever (*)	Stroke	single act		
	Direction	Lever cal	double act		
	Character			linear	
	Cust chr	#of points		equal %	
	Curr range	Cust curve	X0=	quick open	
			Y0=	custom	
	Trvl range	0% =	0% =	sq root	
		100%=	Set 0%		
			Set 100%		
	Trvl ctrl	Set low	free	direct	
		Set high	cutoff	reverse	
		Values	limited		
	Transm.	Cutoff Low	Limit Low	Position	
		Limit Hi	Limit Hi	Set Point	
	Passcode	Old	New 0=Off	D3-38	
	Auto PST			D3-81	
	Fail. Mode			(**)	
	Appearance	Language	English	Message	
			Svenska	Tag	
			Deutsch	Descriptor	
			français	Date	
			italiano	Device ID	
			español	Poll adr	
		Units	Setpoint	Assemblyno	
			Position	HW rev	
			Pressure**	SW rev	
			Temp	Capability	
				Hart	
				Burst	
				Pos (PV)	
				Set (SV)	
				4 Dynamic	
TUNING	Close time	Control (x)	P.I.D		
	Open time	Togglestep	K,Ti,Td		
	Deadband	Self test	Min Pulse		
	Expert	leakage	ShootProte		
		Undo	Spring Adj		
			Red. #Pulses / Disable		
				run time	
				cycle time	
				size	
				start	
				Abort step	
ALARMS	Deviation				
	Limit 1	On/off		On/off	
	Limit 2	Minpos		Distance	
		Maxpos		Time	
		Hysteresis		Alarm out	
		Alarm out		Valve act	
	Pos=Pres	On/off	Maxdiff		
		Valve act	Valve act		
	Pressure	On/off	Min Pres		
		Valve act	Max Pres		
	Temp	On/off	Hysteresis		
		Valve act	Alarm out		
			Valve act		
			Low temp		
			High temp		
			Hysteresis		
			Alarm out		
			Valve act		
				no action	
				goto open	
				goto close	
				manual	
FACT SET	no				
	yes				

(*) appear if Linear set
(**) appear if pressure sensor exist

8. Maintenance/service

When carrying out service, replacing a circuit board, etc., it may be necessary to remove and refit various parts of the positioner. This is described on the following pages.

Read the Safety Instructions on page 3 and 4 before starting work on the positioner.

Cleanliness is essential when working with the positioner. Contamination in the air ducts will infallible lead to operational disturbances. Do not disassemble the unit more than that described here.

Do not take the valve block apart because its function will be impaired.

When working with the PMV D3 positioner, the work place must be equipped with ESD protection before the work is started.



Always turn off the air and electrical supplies before starting any work.





Please see section for special conditions for safe use and spare parts on page 4!

Please contact a Flowserve office for information regarding proper procedures.
www.pmv.nu or infopmv@flowserve.com

Disassembling PMV D3

Removing cover and inner cover

- Unscrew the screws A and remove the cover. When mounting cover – see page 9.
- Pull off the arrow pointer, B, using a small screw driver.
- Unscrew the screws C, pull the inner cover slightly in the direction of the arrow, and remove the cover. Do not remove the filter plug.




Circuit boards (pcb)




Disconnect or switch off the electric power supply before starting any work.


- Lift off the display pcb, D.



- Release the cable connections E, F and G,



- Unscrew the spacers H and lift up the terminal board I.




Valve block



Turn off the air and electric power supply before starting any work.

- Remove the four screws I and lift out the valve block




N.B. Do not disassemble the valve block

- When installing the valve block — torque the four screws cross-wise to 2,5 Nm and seal with Locktite 222.

Silencer

A silencer, L (option) can be mounted under the plate M on the PMV D3. Contact PMV.




Potentiometer

90° and 270° spring loaded potentiometer

The spring-loaded potentiometer **K** can be removed from the gearwheel for calibration or replacement.

If the potentiometer is replaced or the setting is changed, it must be calibrated.

- Select the menu Calibrate - Expert - Cal pot. The display shows Set gear (1).
- Turn the spindle shaft (2) cw to end position and press OK. Turn ccw to the end and press OK.
- Unmesh the potentiometer (3) and turn it according to display until OK is shown. Press OK.
- Re-align spring on potentiometer to secure it.




Transmitter boards

The equipment for transmitter feedback consists of a circuit board A, cam assembly B and screws.

General pcb versions:

- with mechanical switches, SPDT
- with namur sensors, DIN 19234
- with proximity switches
- with feedback transmitter and/or remote only







Transmitter board installation




Caution! Turn off the power and air supply before starting the installation.

**Important for PMV D3 units with hazardous approvals:
Maintenance and repairs only to be made by authorized staff.**


- Remove the cover, indicator and inner cover according to the description on page 36.
- Check that both spacers **C** are installed.
- Carefully mount the circuit board in its position. The pins **D** should fit in the connector and the positioners motherboard. Make sure that the feedback PC board is properly connected.
- Secure the circuit board with the enclosed screws **E**.
- Install the cam assembly **B** on the shaft and push it down to its position. If the board has microswitches, be careful not to damage the levers.




- Tighten the screws **F**, on the cam assembly. Do not tighten the screws too hard. The cams should be able to move in relation to each other.




- Install the inner cover with the two screws, **G**.
- Connect the wiring for the transmitter feedback on the terminal block, according to the drawing on next page.



- Adjust the position where the switches/sensors should be affected, by turning the cams with a screwdriver.




- Tighten the cam assembly screws **F** when the cams are correctly adjusted.
- Install the indicator and cover. To calibrate the feedback transmitter, see drawing on next page.



Disassembling PMV D3 Ex

- Loosen the screws **A** and **B** and remove the caps **C** och **D**.
- Remove the inner display cover **E** by loosening the four screws **F**.
- Carefully remove the display board and loosen the connection **H** and **I**.
- Release the wide cable from the connector **J** on the terminal board.
- Loosen the three screws **K**.
- Remove the circuit board package **L**, consisting of terminal and processor board.
- Remove the four screws **M** and lift the block **N**.
- Pressure sensor board **O**, (option) can only be moved after the block **N** is removed.




Filter change



Turn off the compressed air supply before starting any work. Otherwise the filter can be blown out of the positioner by the air pressure, which can be dangerous.

- Remove the filter cap using a coin of suitable size.
- **Note!** Do not use a screwdriver. The filter cap might crack and cause air leakage.
- When installing the filter/filter plug, start by installing the O-ring in the **bottom** of the cavity in the pneumatic block. Do *not* try to install it on the threaded filter plug. Insert filter in the filter plug, then thread the filter plug into pneumatic block.



9. Trouble shooting

Symptom	Action
Input signal change to positioner does not affect actuator position.	<ul style="list-style-type: none"> • Check air supply pressure, air cleanliness, and connection between positioner and actuator. • Out of service, in manual mode. • Check input signal to positioner. • Check mounting and connections of positioner and actuator.
Change in input signal to positioner makes actuator move to its end position.	<ul style="list-style-type: none"> • Check input signal. • Check mounting and connections of positioner and actuator.
Inaccurate control.	<ul style="list-style-type: none"> • Perform Auto-calibration and check for any leaks. • Uneven air supply pressure. • Uneven input signal. • Wrong size of actuator being used. • High friction in actuator/valve package. • Excess play in actuator/valve package. • Excess play in mounting of positioner on actuator. • Dirty/humid supply air.
Slow movements, unstable regulation.	<ul style="list-style-type: none"> • Implement auto-tuning. • Increase the deadband (Tuning menu). • Adjust Performance (Calibrate menu).

10. Technical data

Rotation angle	min. 30° max 100°, option 270°
Stroke	5-130 mm (0.2" to 5.1")
Input signal	4-20 mA DC
Air supply	2-7 bar (30-105 psi) DIN/ISO 8573-1 3.2.3 Free from oil, water and moisture.
Air delivery	350 nl/min (13.8 scfm)
Air consumption	<0.3 nl/min (0.01 scfm)
Air connections	1/4" G or NPT
Cable entry	3 x M20x1,5 or 1/2" NPT (D3E 2x)
Electrical connections	Screw terminals 2.5 mm ² /AWG14
Linearity	<1%
Repeatability	<0.5%
Hysteresis	<0.4%
Dead band	0.2-10% adjustable
Display	Graphic, view area 15 x 41mm (0.6 x 1.6")
UI	5 push buttons
CE directives	93/68EEC, 89/336/EEC, 92 /31/EEC
EMC	EN 50 081-2, EN 50 082-2
Voltage drop, without HART	< 8.0 V => resistance 400 Ω
Voltage drop, with HART	< 9.4 V => resistance 470 Ω
Vibrations	<1% up to 10 g at frequency 10-500 Hz
Enclosure	IP66/NEMA 4X
Material	Die-cast aluminium, A2/A4 fasteners
Surface treatment	Powder epoxy
Temperatur range	-30 to +80°C (-22 to 176° F)
Weight	PMV D3X, 1.4 kg (3 lbs). PMV D3E, 3 kg (6.6 lbs) PMV D3E Stainless Steel, 6 kg (13.2 lbs)
Alarm output	Transistor Ri 1 KΩ
Alarm Supply Voltage	8-28 V DC
Mounting position	Any

Mechanical switches

Type SPDT
 Size Sub Sub miniature
 Rating 3 A/125 VAC / 2 A/30 VDC
 Temp. range -30°C to 80°C (-22°F to 180°F)

NAMUR sensors (NJ2-V3-N)

Type Proximity DIN EN 60947-5-6:2000
 Load current $1\text{ mA} \leq I \leq 3\text{ mA}$
 Voltage range 8 VDC
 Hysteresis 0.2 %
 Temp. range -25°C to 85°C (-13°F to 185°F)

Proximity switches

Type SPDT
 Rating 0.4A @ 24VDC, Max 10W
 Operating time Max 1.0 ms
 Max voltage 200 VDC
 Contact resistance 0.2 Ω
 Temp. range -30°C to 80°C (-22°F to 180°F)


Slot NAMUR switches (SJ2-S1N, SJ2-SN, SJ2-N)

Type Proximity DIN EN 60947-5-6:2000
 Load current $1\text{ mA} \leq I \leq 3\text{ mA}$
 Voltage 8 VDC
 Hysteresis 0.2 %
 Temp -25°C to 85°C (-13°F to 185°F)


4-20 mA transmitter

Supply 9-28 VDC
 Output 4-20 mA
 Resolution 0.1 %
 Linearity full span +/-0.5 %
 Output current limit 30 mA DC
 Load impedance 800 Ω @ 24 VDC


11. Dimensions




Dimensions with optional gauge block installed



Dimensions explosion proof version




12. Spare parts



General Purpose and Intrinsically safe housing

No	Part no	Description
1	D3-SP6	Black cover incl. Screws
2	D3-SP11	Internal cover incl. screws
3	P3-SP13	Cover plate incl. screw
4	3-SXX	Spindle adaptor (XX = 01, 02, 06, 26, 30, 36, 40, 41)
5	3-AS23	S23 Shaft compl. Incl. gearwheel, friction clutch, spring
5	3-AS39	S39 Shaft compl. Incl. gearwheel, friction clutch, spring
5	3-AS09	S09 Shaft compl. Incl. gearwheel, friction clutch, spring
6	D3-SP1	Block complete, incl cable, rubber seal, filter plug
6	D3-SP1-PS	Block complete, Pressure sensors, incl cable, seal, filter plug
6	D3-SP1-FF	Block complete, incl cable, rubber seal, filter plug, Fail Freeze
6	D3-SP1-PFF	Block complete, Pressure sensors, incl cable, rubber seal, filter plug, Fail Freeze
7	D3-SP9	Filterplug, incl. O-ring, filter
8	3-SP8B	Potentiometer compl. incl. spring, holder, cable
9	3-SP37HR	PCB LCD Display assy Hi Res type
10	D3-SP35P	PCBs (Terminal and processor) Profibus
10	3-SP80X	PCB Motherboard
10	3-SP80H	PCB Motherboard HART
11	3-SP84	Pressure sensor PCB assy complete.
12	3-SP48A	Indicator arrow assy
13	D3-SP/SCREW	Kit, bag with screws
14	D3-SP/SEAL	Kit, bag with O-rings, seals
16	D3-SP34G	Gauge block G, complete
16	D3-SP34N	Gauge block NPT, complete
17	3-AS81T	PCB Transmitter 4-20mA assy
17	3-AS81M	PCB Transmitter and Mechanical switches, assy
17	3-AS81N	PCB Transmitter and Namur sensors, assy
17	3-AS81P	PCB Transmitter and Proximity switches, assy
17	3-AS81N4	PCB Transmitter, slot type Namur sensors(P+F SJ2 S1N), assy
17	3-AS81N5	PCB Transmitter, slot type Namur sensors(P+F SJ2 SN), assy
17	3-AS81N6	PCB Transmitter, slot type Namur sensors(P+F SJ2N), assy
18	D3-67	Silencer, Sintered brass
	D3-SP/REPAIR KIT	



Explosion proof housing

No	Part no	Description
3	D3E-SP4	Internal cover incl. screws
5	D3-SP1	See D3 page 53
5	D3-SP1-PS	See D3 page 53
7	3E-SP8	Potentiometer compl. incl. spring, holder, cable
8	3-AS23	S23 Shaft compl. Incl. gearwheel, friction clutch, spring
8	3-AS39	S39 Shaft compl. Incl. gearwheel, friction clutch, spring
8	3-AS09	S09 Shaft compl. Incl. gearwheel, friction clutch, spring
9	3E-SP80X	PCB Mother board
9	3E-SP80XT	PCB Mother board, 4-20mA transmitter
9	3E-SP80H	PCB Mother board HART
9	3E-SP80HT	PCB Mother board, HART 4-20mA transmitter
10	3-SP84	See D3 page 53
11	3-SP37HR	See D3 page 53
12	3E-SP83	PCB Terminals
13	D3E-SP/SCREW	Kit, bag with screws
14	D3E-SP/SEAL	Kit, bag with O-rings, seals

Notes

Palmstierna International AB

Korta Gatan 9
SE-171 54 SOLNA
SWEDEN
Phone: +46 (0)8-555 106 00
Fax: +46 (0) 8 555 106 01
E-mail: infopmv@flowserve.com

PMV USA

14219 Westfair West Drive
Houston, TX 77041, USA
Tel: +1 281 671 9209
Fax: +1 281 671 9268
E-mail: salespmv@flowserve.com

Flowserve Flow Control (UK) Ltd.

44 Victoria Way, Burgess Hill
West Sussex, RH15 9NF
UNITED KINGDOM
Tel: +44 (0) 1444 884846
E-mail: pmvuksales@flowserve.com

Flowserve Flow Control Benelux

Rechtzaad 17
4703 RC Roosendaal
THE NETHERLANDS
Tel: +31 (0) 30 6771946
Fax: +27 (0) 30 6772471
E-mail: fcbinfo@flowserve.com

Flowserve Flow Control GmbH

Rudolf-Plank Strasse 2
D-76275 Ettlingen
GERMANY
Tel: +49 (0) 7243 103 0
Fax: +49 (0) 7243 103 222
E-mail: argus@flowserve.com

Flowserve Spa

Via Prealpi, 30
20032 Cormano (Milano)
ITALY
Tel: +39 (0) 2 663 251
Fax: +39 (0) 2 615 18 63
E-mail: infoitaly@flowserve.com

Flowserve Corporation

No. 35, Baiyu Road
Suzhou Industrial Park
Suzhou 215021, Jiangsu Province,
PRC
Phone: +86-512-6288-1688
Fax: +86-512-6288-8737

Flowserve Australia Pty Ltd

Flow Control Division
14 Dalmore Drive
Scoresby, Victoria 3179
Australia
Phone: +61 3 9759 3300
Fax: +61 3 9759 3301

Flowserve Pte Ltd

No. 12 Tuas Avenue 20
Singapore 638824
Phone: +65 6879 8900
Fax: +65 6862 4940

Flowserve do Brasil Ltda

Rua Tocantins, 128 - Bairro Nova Gerti
São Caetano do Sul,
São Paulo 09580-130 Brazil
Phone: +5511 4231 6300
Fax: +5511 4231 6329 - 423

flowserve.com

To find your local Flowserve representative:

To find your local Flowserve representative please use the Sales Support Locator System found at www.flowserve.com

FCD PMENIM0001-03 - 12/14

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful life. However, the purchaser or user of Flowserve products should be aware that Flowserve products might be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can provide general guidelines, it cannot provide specific data and warnings for all possible applications. The purchaser/user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation, and maintenance of Flowserve products. The purchaser/user should read and understand the (D3 Digital Positioner User Instructions) instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its worldwide operations or offices.

For more information about Flowserve Corporation, contact www.flowserve.com or call USA 1-800-225-6989.

© December 2014, Flowserve Corporation, Irving, Texas